

Fire fittings (cont.)	Page #	Fire fittings (cont.)	Page #	Flanged (cont.)	Page #
Hose	775	Angle	865, 869	ANSI	83
Hump	775	500#	853	Combination nipple	10, 361
Covers	775	Cast	852, 854	Dry aviation	104
Pin		Forged	855	Dry disconnect	94
Covers	776	Ball	863	Dry quick disconnect	99, 100
Hose assembly	776	Chicago pattern	870	External swage fixed	576
Nipples	776	Drain	871	External swage floating	576
Semi-automatic	776	Drip, ball	864	Quick-connect, fittings	378, 379, 383, 384
Wall bracket	776	Gate		Safety break-away	105, 106, 143
Reels	771	Hydrant	859	Swivels	132, 136
Continuous flow	773	Hydrant, global	859	Tank truck .. 118, 119, 121, 122, 123, 1025, 1026, 1031, 1032	
Accessories	773	Hydrant, single	858, 859	Weld fittings	118
Covers	773	Large diameter	860	Tee	1031
Global continuous flow	772	Wedge disc	856, 857	TTMA extensions	119, 134
Cover	772	Globe	864, 866	Weld adapters	171
Replacement inlet swivel joint	772	Pressure reducing	867, 868	Flanges	624, 704, 956
Style V swing type	770	Relief	872	150 Lb.	956, 957
Covers	770	Sprinkler hose	871	Adapters	964
Swing type	771	Wye	861, 862, 863	ANSI flat face	957
Covers	771	Wall hydrants		ANSI Split	964
Heavy duty, high capacity	771	Exposed 2-way	847	Boss ductile	955
Pipe brackets	771	Wall plates		Floating	956
Siamese assemblies		For concealed 3-way bodies	845	Gaskets	122, 957, 1025
Double clapper concealed type ..	846	For double clapper	845	Hydraulic	
Two way sidewalk	846	Washers		Pipe socket weld	565
Siamese body	842	Swivel	767	Lap joint	955, 956
Snoots		Tail	767	NPT	956
Clapper type, pin lug	845	Wharf hydrants	861	Slip-on	118, 955, 956, 1031
Spring check type, pin lug	844	Wrenches		Socket weld butterfly valve	952
Sprinkler line tester	851	Adjustable		Stub end	955
Storz	827, 828, 831	Double head	829	TTMA	10
Accessories	827	Hydrant	829	Weld neck	957
Adapters	823, 826	Pigtail	829	Flare fittings	984, 985, 986
Caps	827	Hydrant	830	37°	543-549, 555, 556
Elbows	825, 826	5 hole	829	Connectors	984
Flanges	825	Adjustable	828, 829	Elbows	545, 546, 547, 985, 986
Gaskets	827	Double head adjustable	829	Nuts	548, 549, 986
Hydrant wrench	828	Pigtail adjustable	829	Tees	986
Locking device	827	Storz	828	Unions	985
Mounting plates (bracket)	827	Spanner	828, 830, 831	Flareless bite fittings	557, 558, 559, 987, 988, 989
Rigid female	822	Folding pocket	828	Adapters	557, 558, 987, 988
Rigid male	824	Forestry	830	Elbows	558, 559, 988, 989
Valves	872	Grip-All	829	Ferrules	559, 989
Wrenches	831	Hole type	828	JIC	557, 987
Suction		Long handle suction	830	37°	557
Elbows	832	Storz, pin lug	831	Nuts	559, 989
Short shank, long handle	832	Universal	828	Tees	559, 989
Swivels		Storz	828, 831	Unions	558, 988
Adapter		Universal	828	Flat face fittings	539, 540
Female to male, pin lug	808	Fire hose		FloMax connectors	
Double female	797	Axe	1066	3/4" series	117
Pin lug	797	Nozzles	779-794	Diesel fueling system .. 109, 110, 111	
Rocker lug	797	Spanner wrenches	372, 828-831	Fuel vent	109, 110, 111, 112
Elbows	832	Flame retardant hose protection .. 1067		Gravity fill receiver	112
Replacement and accessories ..	821	Flange		High flow 1" series	117
Storz		Code 61 / Code 62 hydraulic		R series	109, 115, 116
Style N35, rocker lug	799	Split flange kit	566	Service box	112
Style N53, rocker lug	798	Flanged		Standard	109, 113, 114
Style N57, long handle	799	Adapters	170, 171, 964	Flow control	
Valves		45° elbow	170	Series F valves	276, 560, 904
		Short	170		
		Straight	170		
		Cam & groove	61, 82		