

TTMA Fittings118 - 123

Flange adapters	118
Slip-on flange	118
Buttweld flange	118
Spacer with 1/2" port	119
Flange extensions	119
Cam and groove	119
Adapter	119
Coupler	119
Dixon® vapor recovery couplers	120 - 121
With probe x adapter	120
With probe x coupler with probe	120
Coupler with probe x hose shank	120
Coupler x 45° hose shank	121
Coupler x female NPT	121
Bayloc® vapor coupler with locking handle	121
EZ Boss-Lock Vapor Recovery Coupler with Probe	121
Flange gaskets	122
Flanged sight flow indicators	122 - 123
Sight flow indicator repair kits	123
Flange screen	123

Railroad tank car connections124 - 127

Style A	124
Style F	124
Style GF	124
Screen	124
Style S	124
Style T	125
Dixon® coupler x tank car thread	125
EZ Boss-Lock x coupler tank car thread	125
Railroad unloading assemblies	126
Dixon tank car adapters	126
Cam and groove railroad tank car gaskets	127
Pin lug wrench	127

Swivels128 - 138

Swivel joint overview	128 - 129
Single plane styles 20, 30	130
Double plane styles 40, 50, 60	130
Triple plane styles 10, 70, 80	131
Ordering Information	132
Loading arm swivels	133
Loading arm swivels replacement parts	133
TTMA flange extensions	134
Loading arm	135 - 138
Overview	135
Split flange	136

Swivels (Cont.)128 - 138

Split flange components	136
TTMA handle kit	137
Counterbalance clamps	137
Top loading valves	138
Top loading Diffusers / T-Deflectors	138

API139 - 144

5500-Series couplers	139
Reelcraft® static discharge reel	140
Overfill protection rack monitors	141
FT590-Series terminal test equipment	141
Compatible systems	142
Rack monitors	142
Rack cords	142
Junction boxes	142
Dixon MannTek break-away coupling	143
Rack cord assemblies	144
Rack cord parts	144

ADS145 - 150

A100 Outalarm® with probe	145
A210 Spillguard® system	146 - 147
Monitors	146
Probes	147
Verification monitor	148
Ground clamp and junction box	148
Outage gauge	149
Gauge rods	149
Cables	149
Accessories	150