

Boss Coupling System 158-169

Overview	158
Ground joint	159-161
Complete couplings with female spud	159
Stems	159
Wing nuts	160
Knurled nut	160
Female spuds	160
Male spuds	161
Double spuds	161
Holedall®	161
Adapters	162
Wing nut caps	162
Washer seal	163-164
Complete couplings with female spud	163
Stems	163
Female spuds	163
Male spuds	164
Double spuds	164
Washers	164
Male stems	165
LP male stems	166
Menders	166
Spud x hose shank	166
Clamps	167-168
2 Bolt type, 2 gripping fingers	167
4 Bolt type, 2 gripping fingers	167
4 Bolt type, 4 gripping fingers	168
6 Bolt type, 3 gripping fingers	168
6 Bolt type, 6 gripping fingers	168
Ground joint air hammer couplings	169

Boss Low Pressure System (LPS)....170 - 178

Components overview	170
Frac fittings	171-172
Complete male / female assembly	171
Female	171
Male with nut	172
Suction service fittings	172
O-rings	172
Short ferrules	172
Hammer union	173-175
Nuts	173
One-Piece	173
Two-Piece	173
Three-Piece	173
100-Series	174
200-Series	174
206-Series	174
Caps and plugs	175
One-Piece adapters	176-177
Flange	176-177

Straight	176
Short	176
45° Elbow	176
150# Flange to weld	177
125# Flange x male NPT	177
Port adapter	177
Elbows	177
King Crimp® style	178-179
Large sleeves	178
Heavy duty	179
Combination nipples	179
Ferrules	179
Butterfly valves	180
Frac pump elbow adapters	181
Vent-Lock® safety cam and groove couplings	182-189
Type A	182
Type C	182
EZ Boss-Lock type C	182
Type D	183
Type E	183
Dust caps	183
Dust plugs	183
EZ Boss-Lock type H dust caps	183
Accessories	184
Handles	184

D