

Dry Disconnects 93-106

Bayloc® style	93 - 95
Coupler x female NPT	93
Greaseless coupler x female NPT	93
Coupler x 90° swivel female NPT	93
Coupler locking kits.....	93
Adapter x female NPT	94
Jump size adapter x female NPT	94
Adapter x 150# ASA flange.....	94
Vapor adapter x female NPSM	95
Cam and groove actuator style couplers.....	95
Bayonet style.....	96 - 97
90° swivel coupler x female NPT	96
Straight coupler x female NPT	96
Keyed straight coupler x female NPT.....	96
Straight swivel coupler x female NPT	96
Keyed straight swivel coupler x female NPT	96
Straight swivel.....	96
Adapter x female NPT	97
Keyed adapter x female NPT	97
Dust plugs.....	97
Dust caps	97
Dixon® MannTek style.....	98 - 106
Coupler hose unit x female NPT	99
Coupler x 150# ASA flange	99
Coupler x TTMA flange.....	99
Dust plugs.....	99
Adapter tank unit x female NPT	100
Adapter tank unit x 150# flange	100
Adapter tank unit x TTMA flange.....	100
Dust caps	100
Steam coupler x female NPT	101
Steam adapter x female NPT.....	101
Dry gas couplings.....	102
Coupler hose unit x female NPT	102
Dust plugs	102
Adapter tank unit x female NPT.....	102
Adapter tank unit x female ACME.....	102
Adapter tank unit x 150# ASA flange	102
Dust caps	102
Dry aviation couplings	103 - 104
Coupler x female NPT.....	103
Coupler x female BSP	103
Dust plug	103
Adapter x female NPT	104
Adapter x 150# ASA flange	104
Dust cap	104
Safety Breakaways.....	105 - 106

Dry Disconnects (Cont.) 93 - 106

Marine series	105
Female NPT coupling	105
Male NPT coupling	105
150# flange	105
Industrial series	106
Female NPT coupling	106
Male NPT coupling	106
150# flange coupling	106
TTMA flanged	106
Cryogenic	107-109

Liquid Natural Gas Couplings 110

Cap and plug.....110

FloMAX Refueling 111-119

Part number cross reference.....	111
Diesel series	112-114
Nozzles	112
Receiver, one-piece body	112
Receiver, two-piece body	112
Non-interchange nozzles and receivers.....	113
2" nozzles and receivers	113
Gravity fill receivers.....	114
Fuel vents	114
Fuel swivels	114
Standard series connectors	115-116
Engine oil nozzles and receivers	115
Coolant fluid nozzles and receivers	115
Hydraulic oil nozzles and receivers.....	116
Transmission nozzles and receivers.....	116
R series	117-118
Engine oil nozzles and receivers	117
Coolant fluid nozzles and receivers	117
Hydraulic oil nozzles and receivers.....	118
Transmission fluid nozzles and receivers	118
High flow series.....	119
3/4" nozzles and receivers.....	119
1" nozzles and receivers	119

TTMA Fittings 120-125

Flange adapters	120
Slip-on flange	120
Buttweld flange	120
Spacer with 1/2" port	121
Flange extensions	121
Cam and groove	121
Adapter.....	121
Coupler.....	121